

<u>ITEM</u>	<u>PART NUMBER</u>	<u>QUANTITY</u>	<u>DESCRIPTION</u>	<u>NEXT ENG. ASSY</u>
1	610-70-0905	1	BAG - POLYETHYLENE 10 x 12	
2	610-70-0901	1	BAG - POLYETHYLENE 3 x 5-1/2	
3		1	PACKING LIST	
4	82-070-008-327	1	BRACKET - BALL IDLING	82-00-21420, 29656
5	809-849-325	4	SCR - CAP HEX HD 1/4-20 x 2	" "

PACKAGING INSTRUCTIONS:

PLACE ITEM #5 IN ITEM #2 AND PLACE IN ITEM #1 ALONG WITH ITEM #4

MOUNTING INSTRUCTIONS:

1. MOUNT ON EITHER 82-00-29656 L.H. OR 82-00-21420 R.H. BOUNCE PLATE ASSEMBLY.
2. REMOVE FRONT CARPET ROLLER FROM ITS MOUNTING BRACKETS AND ROLL IT TO THE MIDDLE OF THE BOUNCE PLATE ASSY BENEATH CARPET.
3. REMOVE THE (4) 1/4-20 x 1-1/4 IG. MOUNTING BOLTS WHICH ARE IN THE BOUNCE PLATE IN THE POSITION WHERE THE BRACKET IS TO BE MOUNTED.
4. PUT LOCTITE #271 ON ENTIRE THREAD PORTION OF THE NEW ITEM #4.
5. PLACE ITEM #4 INTO POSITION AND INSERT THE (4) ITEM #5 BOLTS WITH LOCTITE, BEING CERTAIN THAT THE ORIGINAL FLAT WASHERS ARE RE-INSERTED IN THE MOUNTING HOLES. THEN DRAW THE BOLTS UP TIGHT.
6. REINSTALL FRONT CARPET ROLLER IN ITS ORIGINAL POSITION.

